

JOOBY Indoor Gateway LoRaWAN 501/502 EU

Manual



INTRODUCTION

This data sheet contains information on the purpose, structure, operation and key technical characteristics of the Jooby Indoor Gateway LoRaWAN (hereinafter—Gateway or Device).

This manual will guide you through the installation, operation, and maintenance of the Gateway.

The models description can be found in Table 1.

Model Description

Table 1

JOOBY Indoor Gateway LoRaWAN 501 EU / 502 EU	
Data transmission technology	LoRaWAN, LTE (available for 501 EU model)
LoRaWAN radio frequency band, MHz / LoRaWAN standard	863–873 / EU 868
LoRaWAN transmitter's radiated power, max mW	25
LTE transmitter's radiated power	Class 4 (33 dBm ±2 dB) for EGSM900 Class 1 (30 dBm ±2 dB) for DCS1800 Class E2 (27 dBm ±3 dB) for EGSM900 8-PSK Class E2 (26 dBm ±3 dB) for DCS1800 8-PSK Class 3 (23 dBm ±2 dB) for LTE-FDD bands
LTE frequency band, Upload/Download, MHz	TE-FDD upload = 1920-1980/1710-1785/2500-2570/ 880-915/832-862; LTE-FDD download = 2110-2170/1805-1880/2620-2690/925-960/791-821 GSM = 900/1800
Built-in LTE antenna gain, dBi	2
External LoRaWAN antenna gain, dBi	3
LoRaWAN channels quantity	8
Connection type	Ethernet 10/100
Special features	RS-485 (optionally)
Operating temperature	from -40 C to +60 C
Case sealing class	IP50

PURPOSE AND TECHNICAL CHARACTERISTICS

The Gateway can perform the following functions, depending on its model:

- The Gateway is an autonomous device, powered via Ethernet (PoE 802.3 af/at, class 4). Depending on its model, the Gateway can also be powered by an internal battery in absence of external power. The battery, in turn, can be charged with a built-in charger.
- The Gateway communicates with radio modules using the LoRaWAN interface over 8 communication channels with SF5-SF12 modulation at 868 Mhz frequency.
- Connection with the LoRaWAN Network server can be established via Ethernet, LTE-FDD, EDGE, or GPRS networks (optionally WiFi), depending on the model.
- The Gateway has a USB port to install software from a flash drive if its existing software is malfunctioning.
- The Gateway is designed in a rectangular DIN-rail plastic case (4 units size). The control module is located inside. Its LED-pcb board indicates the status of the Device's power supply and the operation of its interfaces (see Table 2.1 and Fig. 1).
- Time precision is ensured by the built-in GNSS module and NTP servers within the network, complemented by RTC (real-time clock) error compensation based on environmental temperature. In absence of external power, the Gateway's clock is powered by a lithium battery.
- Automatic software updates from the update server if a new version or settings are available.
- The Gateway has a web UI for remote setup and device management.

Gateway indicators guide

Table 2.1

LED name	Color	Description and purpose
POWER	green	Connected to PoE
BAT	green red	Battery charge: —battery fully charged —battery charging
SYSTEM	green red	Gateway mode —active mode/successful loading —power-saving mode/error
ALARM	red	Unauthorized case opening
NET	green	LTE connection established
LINK/ACTIVITY	yellow	Connection / Activity
LoRa_NET	blue	LoRaWAN server connection established

See Table 2.2 for the Gateway's technical characteristics


Table 2.2

Attribute	UOM	Value
PoE voltage range	V	42...57
Active power consumption, less or equal	W	10
Total power consumption, less or equal	V•A	10
Absolute clock error per day, less or equal	s	2
Standard clock deviation per day at 25 °C	s	± 0.5
Lithium battery service life (normal operation / no power)	year / hour	10 / 20 000
Dimensions	mm	107 x 70 x 59
Weight, less or equal	kg	0,160

- Users can read the following main parameters from the Dashboard: Gateway external panel indicators; CPU temperature and Gateway internal temperature; tamper and charging statuses; LoRaWAN network analytics; status of other network interfaces.
- Gateway access can be configured via a web UI or SSL for either a single network interface or all of them.
- Users can check the system error log.
- Gateway settings can be saved and restored.
- Vandalism prevention—custom factory settings prevent theft and further operation of the device.
- Gateway settings can be reset to custom or general factory settings, depending on the device. In addition, users can apply custom settings (user passwords, network parameters, etc.).

The Gateway is intended for continuous 24/7 operation both indoors and outdoors in case of device mounting inside of electrical cabinet. If operating conditions are met, the device is resistant to environmental temperatures ranging from -40 °C to +60 °C and relative humidity of 90% at 25 °C. Mean time to failure with a failure probability of 0.8—at least 24,000 hours.

Figure 1—Gateway appearance, overall dimensions, and installation dimensions



PARTS LIST

Name	JOOBY Outdoor Gateway LoRaWAN 501 EU	JOOBY Outdoor Gateway LoRaWAN 502 EU
	Quantity	
Gateway		1 pcs
Manual		1 copy
LoRaWAN antenna		1 pcs
LTE antenna	1 pcs	not available
Packaging		1 pcs

Note. Can be shipped in multi-piece transport packaging

OPERATION AND STORAGE

Before installing the Gateway on site, perform an external examination and ensure that all the required parts are available and there is no mechanical damage.

The Gateway can be installed on flat surfaces / wall or DIN-rail, utilizing the special fixtures provided with the device.

Steps to install, connect, and start the Gateway:

1. To mount the Gateway on a flat surface, use the corresponding standard fixture as shown in Fig.1. To mount the Gateway on a support, insert the mounting brackets into the openings of the support supplied with the device, as illustrated in Fig.1 on the back of the Gateway case. The appearance, overall dimensions, and installation dimensions of the Gateway are shown in Fig.1.
2. Connect the external antenna (-s) from the Parts list to corresponding plugs at the case of the device as shown in Fig.1.
3. Connect the Ethernet cable to the corresponding LAN port on the built-in control module and check the indicators to ensure that all functional nodes are powered and operational. The indicators are explained in Table 1. Insert a SIM card (if available) into the slot. It should support GSM, LTE, EDGE, GPRS modes.

Warning! If the dashboard lithium battery is low, replace it with a new lithium battery of the same type (CR2032).

The Gateway can be shipped in packaging via any transportation mode, providing its protection from direct exposure to precipitation. The Gateway can be transported at temperatures ranging from -40 °C to +85° C. The level of dust, acid, and alkali vapors, aggressive gasses and other harmful contaminants that cause corrosion in storage facilities should not exceed the level of corrosive agents for C1 atmosphere.

5

MANUFACTURER'S WARRANTIES

The manufacturer guarantees that the device meets the requirements specified in the technical documentation, provided that the user ensures proper installation and operating conditions. The manufacturer guarantees that the radio equipment can operate in Ukraine as intended without violating the established conditions for the use of Ukraine's radio frequency resource.

Warranty period—24 months from delivery date, but no more than 30 months from manufacture date. During this period, the manufacturer offers warranty repair services for the device. Follow the link to learn more about the conditions and exceptions for warranty service: www.jooby.eu/warranty-en/

Service center: Telecommunication Technologies LLC. 4D Nebesnoi Sotni Ave., Odesa, 65121, Ukraine. Tel.: +38 (048) 759-09-00. Email: warranty@infomir.com.

Trademarks

Jooby is a trademark of Telecommunication Technologies LLC (hereinafter—the Company). All rights reserved. This document contains information that is proprietary to the Company. No part of this document may be copied, replicated, transferred, transcribed, stored in a retrieval system, altered or translated into any other language, including computer languages, and sub-licensed in any way—electronic, mechanical, optical, chemical, manual, etc.—without the Company's prior written consent. Any unauthorized use of the materials contained in this document by any person will render that person liable for the losses incurred by the Company.

LoRaWAN is a trademark owned by LoRa Alliance.

Conformity Assessment

EU

Hereby, Telecommunication Technologies LLC declares that the Jooby Indoor Gateway LoRaWAN is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://jooby.eu/declarations-en/>

UK

Hereby, Telecommunication Technologies LLC declares that the Jooby Indoor Gateway LoRaWAN is in compliance with the Radio Equipment Regulations 2017. The full text of the EU declaration of conformity is available at the following internet address: <https://jooby.eu/declarations-en/>

Warning! The Gateway utilizes a lithium battery that is not accessible to users. Only a qualified technician is permitted to open the device and replace this component.

6

DAMAGE LOG

Damage registration date	Conclusion	Signature, stamp

ACCEPTANCE CERTIFICATE

Gateway: _____
complies with all design documentation and is recognized as suitable for operation.

The manufacturer reserves the right to modify the design or specifications of the device at their discretion, provided that such changes do not impair its functional characteristics. Hence, the manufacturer reserves the right to alter the appearance and the components outlined in this manual without prior notification to consumers.

Model serial number

Date of sale _____



Manufacturer:
TELECOMMUNICATION TECHNOLOGIES LLC
1, Mytna Square, Odesa, 65026, Ukraine

e-mail: rdc@jooby.eu
www.jooby.eu

7

8



This device contains a lithium battery

Fire, explosion and severe burn hazard. Do not recharge, crush, disassemble, heat above 212 °F (100 °C), incinerate, short circuit or expose contents to water.



The crossed-out wheeled bin symbol indicates that all electrical and electronic products and batteries must be collected separately at the end of their working life. Do not dispose of these products with unsorted municipal waste: take them for recycling. For information on the nearest recycling point, please contact your local waste authority.